PTX-FLA
PTX Flashlight Attachment Kit
(Battery Included)

PTX-FLA

Installation Instructions

1. Loosen housing nut

2. Slide unit on to the PTX tool

3. Tighten housing nut

Housing Nut

Note: The flashlight uses a standard AAA battery, which is easily replaced by unscrewing the end cap.

ok JONARDTOOLS®

134 Marbledale Road • Tuckahoe, NY 10707
Tel: 914-793-0700 • Fax: 914-793-4527
E-mail: sales@jonard.com
www.jonard.com